

DURAWELL & SLATEWELL EGRESS WINDOW WELL COVER

INSTALLATION INSTRUCTIONS

INCLUDES

- (6) Dual-Lock Discs
- (6) Dual-Lock Self-Adhesive Pads
- (6) 3/4" Screws

INSTALLATION

1. You will be installing (6) Dual-Lock Disc and Pads to your well and cover.

a. (2) will be installed 8" from the foundation wall, centered on the rim of the well.

b. (2) will be installed 30" from the foundation wall, centered on the rim of the well.

c. (2) will be installed 10" from the center point of the well.

2. Using a marker or pencil and a tape measure, measure and mark all (6) hardware locations. NOTE: Be sure to make markings as close to the center of the rim as possible.

3. Attach (6) Dual-Lock Discs at marked locations using the screws provided.

4. Once the Dual-Lock Discs are attached, place your window well over the well, ensuring it is centered. Use your pencil or marker to mark the center of the Dual-Lock Discs.

5. Using these marks, remove backing from each Dual-Lock Self-Adhesive Pad and adhere them to the underside of the cover. NOTE: Each pad should be placed so it can attach to the corresponding disc.

6. Let the adhesive cure for at least 1 hour. Once cured, align each Dual-Lock Self-Adhesive Pad with the corresponding Dual-Lock Disc and firmly press down until you feel the structures interlock.

