



Mar-flex Waterproofing and Building Products / 500 Business Pkwy / Carlisle, OH 45005
 Toll Free: (800) 498-1411 / Main Phone: (513) 422-7285 / Fax: (513) 422-7282
 E-mail: info@mar-flex.com
www.Mar-flex.com

This specification specifies **QuickSeal™ Water-based Waterproofing Membrane**. This product is manufactured by Mar-flex Waterproofing and Building Products. Revise section number and title below to suit project requirements, specification practices and section content. Refer to CSI MasterFormat for other section numbers and titles.

This specification utilizes the Construction Specifications Institute (CSI) Manual of Practice, including MasterFormat™, SectionFormat™ and PageFormat™. This is a manufacturer-specific proprietary product specification using the proprietary method of specifying applicable to project specifications and master guide specifications. Optional text is indicated by brackets []; delete optional text in final copy of specification. Specifier Notes typically precede specification text; delete notes in final copy of specification. Trade/brand names with appropriate symbols typically are used in Specifier Notes; symbols are not used in specification text. Metric conversion, where used, is soft metric conversion.

SECTION 07140 FLUID-APPLIED WATERPROOFING

PART 1 GENERAL

1.01 SUMMARY

A. Section Includes: Fluid-Applied Waterproofing.

Specifier Note: Article below may be omitted when specifying manufacturer's proprietary products and recommended installation. Retain Reference Article when specifying products and installation by an industry reference standard. If retained, list standard(s) referenced in this section. Indicate issuing authority name, acronym, standard designation and title. Establish policy for indicating edition date of standard referenced. Conditions of the Contract or Division 1 References Section may establish the edition date of standards. This article does not require compliance with standard but is merely a listing of references used. Article below should list only those industry standards referenced in this section.

B. Related Sections:

1. Section 02320 – Backfill
2. Section 02620 – Subdrainage
3. Section 07212 – Board Insulation: Perimeter and horizontal insulation

1.02 REFERENCES

A. American Society for Testing and Materials (ASTM):

1. ASTM C-836 Standard Specification for High Solids Content, Cold Liquid-Applied Elastomeric Waterproofing Membrane for Use with Separate Wearing Course.
2. ASTM D-412 Standard Test Methods for Vulcanized Rubber and Thermoplastic Rubbers and Thermoplastic Elastomers-Tension.
3. ASTM D-2939 Standard Test Methods for Emulsified Bitumens Used as Protective Coatings.
4. ASTM E-96 Standard Test Methods for Water Vapor Transmission of Materials.
5. ASTM D-3273 Standard Test Method for Resistance to Growth of Mold on the Surface of Interior Coatings in an Environmental Chamber.
6. ASTM D-3274 Standard Test Method for Evaluating Degree of Surface Disfigurement of Paint Films by Microbial (Fungal or Algal) Growth or Soil and Dirt Accumulation.

1.03 SUBMITTALS

- A. General: Submit listed submittals in accordance with Conditions of the Contract and Division 1 Submittal Procedures Section.
- B. Product Data: Submit manufacturer's product data and installation instructions.
- C. Quality Assurance/Control Submittals: Submit the following:
 1. Certificates: Submit certificate that applicator complies with requirements of this section.

Specifier Note: Article below should include prerequisites, standards, limitations and criteria that establish an overall level of quality for products and workmanship for this section. Coordinate article below with Division 1 Quality Assurance Section.

1.04 QUALITY ASSURANCE

Specifier Note: Paragraph below should list obligations for compliance with specific code requirements particular to this section. General statements to comply with a particular code are typically addressed in Conditions of the Contract and Division 1 Regulatory Requirements Section. Repetitive statements should be avoided.

- A. Regulatory Requirements and Approvals: Comply with requirements of the following:
 - 1. ICC Evaluation Service, Inc. (ICC-ES)
 - a. ESR-3062

Specifier Note: Article below should include special and unique requirements. Coordinate article below with Division 1 Product Requirements Section.

1.05 DELIVERY, STORAGE & HANDLING

- A. General: Comply with Division 1 Product Requirement Section.
- B. Delivery: Deliver materials in manufacturer's original, unopened, undamaged containers with identification labels intact.
- C. Storage and Protection: Store materials protected from exposure to harmful environmental conditions and at temperature and humidity conditions recommended by the manufacturer.

1.06 PROJECT/SITE CONDITIONS

A. Environmental Requirements: Comply with application temperature range of 20-130°F for Water-Based product.

1.07 WARRANTY

- A. Manufacturer's material warranty may be available.

PART 2 PRODUCTS

Specifier Note: Retain article below for proprietary method specification. Add product attributes, performance characteristics, material standards and descriptions as applicable. Use of such phrases as "or equal" or "or approved equal" or similar phrases may cause ambiguity in specifications. Such phrases require verification (procedural, legal and regulatory) and assignment of responsibility for determining "or equal" products.

2.01 FLUID-APPLIED WATERPROOFING

Specifier Note: Paragraph below is an addition to CSI SectionFormat. Retain or delete paragraph below per project requirements and specifier's practice.

- A. Manufacturer: Mar-flex Waterproofing and Building Products
 - 1. Contact: 500 Business Pkwy, Carlisle, OH 45005; Telephone: (800) 498-1411, (513) 422-7285; Fax: (513) 422-7282; E-mail: info@mar-flex
 - 2. Website: www.Mar-flex.com.
- B. Proprietary Products/Systems should be purchased through an Authorized Dealer of Mar-flex Products.
- C. Fluid-Applied Waterproofing and related products, including the following:

Specifier Note: Select method of application to suit project requirements and specify below.

- 1. Quick Seal Waterproofing Membrane:
 - a. Material: Emulsion.
 - b. Total Solids: 60-70%
 - c. Application Method: [Spray] [Brush] [Roll].
 - d. Elongation at 70°F (21°C): 1320% min.
 - e. Total Cure Time: 24 hours.
 - f. Tensile Strength (ASTM D-412): 32 psi (221 kPa).
 - g. Weight/Gallon: 8.03 lb (3.64 kg).
 - h. Coverage Rate: 3.3 – 5.0 gal/100 ft²
 - i. Film Thickness, Wet: 55 mil-Dry: 40 mil (1.5 mm) min.
 - j. Color: Black.
 - k. Crack Bridging (ASTM C-836): 10 cycles without bond failure.
 - l. Resistance to Water Flow (ASTM D-466): Bond strength not affected.
 - m. Water Solubility (ASTM D-2939): No blistering or re-emulsion.
 - n. Water Vapor (ASTM E-96):
 - i. Transmission: 0.12 grains/sf/h.
 - ii. Permeability: 0.29 perms (16 ng/(Pa × s × m²)).

- o. Resistance to Growth of Mold - Surface Disfigurement (ASTM D-3273, ASTM D-3274): None.
- 2. Drain & Dry Insulation/Drainage Board:
 - a. Material: Inorganic glass fiber
 - b. Thermal Resistance: 3.1 - 10
 - c. Foundation Drainage Rate: Up to 65 gal/hr/lin ft
- 3. ShockWave 1 or 2 Foundation Insulation/Drainage Board:
 - a. Material: Closed Cell Foam Board
 - b. Thermal Resistance: 9.0 - 13.50
 - c. Foundation Drainage Rate: Up to 101.11 gal/hr/lin ft
- 4. Geo-Mat™ Plus Drainage Roll:
 - a. Material: High Density Polyethylene (HDPE) drainage rolls with attached polypropylene geotextile mat.
 - b. Foundation Drainage Rate: 18 gal/min/ft
- 5. Type I / "C" Drain 110 Dimpleboard:
 - a. Material: Polystyrene compressed into a light-duty dimpled core bonded to a single layer of non-woven filter fabric.
 - b. Foundation Drainage Rate: 9 g/pm/ft width
- 6. Type II / "C" Drain 150 Dimpleboard:
 - a. Material: Polystyrene compressed into a moderate-duty dimpled core bonded to a single layer of non-woven filter fabric.
 - b. Foundation Drainage Rate: 21 g/pm/ft width
- 7. Type III / "C" Drain 400 Decking Drainage:
 - a. Material: Polystyrene compressed into a moderate-duty dimpled core bonded to a single layer of non-woven filter fabric.
 - b. Thermal Resistance: R 2.8 – 10.2

Specifier Note: Edit Article below to suit project requirements. If substitutions are permitted, edit text below. Add text to refer to Division 1 Project Requirements (Product Substitutions Procedures) Section.

2.02 PRODUCT SUBSTITUTIONS

- A. Substitutions: No substitutions permitted.

2.03 ACCESSORY MATERIALS

- A. Provide proprietary accessory materials, including the following:

Specifier Note: Specify mastic below to patch cracks, voids and holes in the concrete or masonry walls, which are to receive waterproofing. Mar-flex 362 Mastic is made of fiberated, trowel grade, asphalt-based mastic, which is fortified with Bio fiber. These materials adhere tightly to form a strong, flexible bond. They may be used in any weather conditions, including applying to damp or cold surfaces, for patching tie holes and honeycombed areas in both rough and smooth masonry surfaces.

- 1. Mar-flex 362 Mastic:
 - a. Material: Plastic or resin material compatible with the waterproofing membrane.

Specifier Note: For horizontal application, specify drainage material to remove drainage water.

- 2. Mar-flex 12" GeoDrain Drain Tile

PART 3 EXECUTION

Specifier Note: Article below is an addition to the CSI SectionFormat. Revise article below to suit project requirements and specifier's practice.

3.01 MANUFACTURER'S INSTRUCTIONS

- A. Comply with the most current written installation instructions and recommendations of the waterproofing manufacturer.

3.02 EXAMINATION

- A. Site Verification of Conditions:
 - 1. Verify that site conditions are acceptable for application of the waterproofing system.
 - 2. Do not proceed with application until unacceptable conditions are corrected.

3.03 PREPARATION

A. Surface Preparation:

1. Ensure that the surfaces to receive waterproofing are structurally sound and free of moisture, dust, mud, loose mortar, fins, metal projections or any substances that would be detrimental to the bonding of the membrane to the surface.
2. Remove wall ties.
3. Patch cracks, voids and holes with nonshrink grout or mastic.

Specifier Note: Coordinate article below with manufacturer's recommended application requirements.

3.04 APPLICATION

- A. Spray apply a uniform coat of waterproofing to entire wall area. Obtain a seamless membrane free of entrapped gasses, with a minimum dry film thickness of 60 mil (1.5 mm).
- B. Apply fluid membrane onto footing area a minimum of 4" (102 mm) to prevent water pooling.
- C. May be applied to "Green" concrete. See also above 3.03/A/1
- D. Allow membrane to cure for 24 hours before placing any backfill against the wall.
- E. Follow the current installation instructions.

Specifier Note: Delete article below if not applicable to project.

3.05 INSULATING/DRAINAGE PANEL INSTALLATION

Specifier Note: Edit, retain or delete paragraphs below to comply with project requirements and specifier practices.

- A. When using the Drain & Dry begin installation of panels after membrane has been applied. Place and secure drainage panels to substrate according to manufacturer's current written instructions.
 1. Install panels from top of footing extending to finish grade level. When Drain & Dry is to be stacked, maintain a factory-equivalent edge at all seams to ensure proper fit and drainage channel alignment.
 2. Secure Drain & Dry to the wall using powder actuated mechanical fasteners. Install top fasteners within 4" (102 mm) of the tops of each panel.
 3. If the board overlaps the membrane once you have reached the grade line, a utility knife or similar tool can be used to cut the boards to the correct height.
- B. When using ShockWave, install after membrane has been applied. Place and secure to substrate according to manufacturer's current written instructions.
 1. While the membrane is still tacky, starting at a corner with the filter fabric side facing out-ward, install the ShockWave Drainage Board horizontally over the sprayed sections of the wall. The boards should be placed side by side, extending from the top of the footers to finished grade.
 2. Apply uniform pressure to the board throughout the surface area, not just the edges and corners. Note: If boards are stacked, maintain a factory-equivalent edge at all seams to ensure proper fit and drainage channel alignment. Using a Geo Clip, secure the ShockWave to the wall at corners and seems.
 3. When securing the ShockWave at the top of the boards, place a Geo Clip at each corner making sure that at least two prongs from the Geo Clip is placed in each board. When securing the ShockWave at the seems, place a Geo Clip in the middle of the boards making sure that there is one prong in each board.
 4. Once the Geo Clips are in place install them using a powder actuated mechanical fastener or concrete nail.
 5. If the board overlaps the membrane once you have reached the grade line, a utility knife or similar tool can be used to cut the boards to the correct height.
- C. When using Geo-Mat Plus, install after membrane has been applied. Place and secure to substrate according to manufacturer's current written instructions.
 1. While the membrane is still tacky, begin installation at a corner. Install horizontally against the waterproofing membrane with the polypropylene geotextile mat side facing out-ward.
 2. Install panels from top of footing extending to finish grade level. If there is overlapping off the membrane once you have reached the grade line, a utility knife or similar tool can be used to cut the rolls to the correct height.
 3. For good adherence, apply uniform pressure throughout the surface area, not just the edges and corners.
- D. When using the 110 or 150, install after membrane has been applied. Place and secure to substrate according to manufacturer's current written instructions.
 1. While the membrane is still tacky, begin installation at a corner. Install horizontally against the waterproofing membrane with the non-woven filter fabric side facing out-ward.

2. Install panels from top of footing extending to finish grade level. If there is overlapping off the membrane once you have reached the grade line, a utility knife or similar tool can be used to cut the rolls to the correct height.
 3. For good adherence, apply uniform pressure throughout the surface area, not just the edges and corners.
 4. When two edges come together from two separate pieces, overlap the dimples to create a continuous coverage of the wall.
 5. If needed, secure the panels to the wall using a powder actuated mechanical fastener or concrete nail.
 6. If board overlaps the membrane once you have reached the grade line, a utility knife or similar tool can be used to cut the boards to the correct height.
- E. When using "C" Drain 400 for flat decking, begin installation after membrane has been applied. Place draincore to substrate according to manufacturer's current written instructions.
1. Unroll the 400, placing gray side down against membrane. To keep in place, use double sided tape, adhesives or nails.
 2. For overlaps, place adjacent sections so that the cores abut. Secure fabric overlap at five foot intervals with glue, tape or nails.
 3. Join roll ends by peeling back fabric and removing 4" of core. Place end panels so that cores abut, then glue, tape or nail fabric overlap.
 4. Make cuts for any drains to allow water to be drained.
 5. Allow 24-hour set time.
 6. Pour desired thickness of concrete over the 400.
- F. Protect installed insulation/drainage panels during subsequent construction.

Specifier Note: Coordinate article below with Division 1 Execution Requirements (Cleaning) Section.

3.06 CLEANING

- A. Clean spillage and soiling from adjacent construction using cleaning agents and procedures recommended by manufacturer of affected construction.